


DELETE EXISTING RECORDINGS

Manually deleting unwanted recordings from your DVR ensures that you keep what you want. Otherwise, older programs are erased automatically to make room for new recordings when DVR storage limit is reached.

1. Press .
2. Use to highlight a recording to erase. Press .
3. Select **ERASE** and press .



4. Press again to confirm.

Tip: You can press to confirm as well.