PROTECT A RECORDING FROM AUTOMATIC DELETION

1. Press RECORDED TV ●.

2. Use ⌄ to highlight the recording you want to protect. Press OK.

3. Highlight **KEEP UNTIL** and press OK.

4. Press ▷ and select **KEEP UNTIL I ERASE**. Press OK to save your options.

MENU

DVR

CONFLICT

APPDAILY

SETTINGS

HELP