







WATCH A RECORDED PROGRAM

1. Press .
2. Use  to select the program you'd like to watch. Press .

 - Select **PLAY** to watch the program.



- Select **RESUME PLAY** to begin play at the point where you previously stopped watching.
3. When a recording is finished playing, a **FINISHED** screen appears. Use  to select **WATCH LIVE TV**, then press  to return to live TV, or choose one of the other options.