



RECORDING WITH EXTRA TIME AT THE END

If you suspect the program you are recording may run longer than the scheduled time (like sports), you can add time to the end of your recording.

1. Press **INFO** after the program has begun recording. Use **UP** and **DOWN** to select **RECORD OPTIONS** and press **OK**.



2. Press **RIGHT** to select **STOP RECORDING - At scheduled end time**. Press **OK**.



3. Choose the amount of time to add to the recording time. Press **OK**.
4. Press **LEFT** to select **SAVE CHANGES**. Press **OK**. Select **WATCH** and press **OK** to return to the program.