



## CTCTV PRIME REMOTE

Your CTCTV Prime remote works not only for CTCTV Prime, but for your TV, DVD player, VCR, and receiver as well. Here are a few tips to get you started:

Press when in the guide to skip forward or backward in 24 hour intervals.

When you press on your remote, it will take you to the last viewed channel. It will also display the last 5 channels viewed. The pop-up will disappear after 10 second or press again to exit the screen immediately.

Press to display the aspect ratio, audio language, and subtitle options.

See the chart below to view the functions of all the buttons on the remote.

### Buttons

	Allows you to control your set-top box
	Allows you to control your tv
	Turns the device you are controlling on and off
	Allows you to control your DVD player
	Allows you to control your receiver
	Displays the main menu
	Returns to the previous menu screen
	Quick access to App Daily

	Moves selection up, down, left, or right
	Selects the highlighted item
	Exits all menu screens and returns to live TV
	Displays a description of the selected program and recording options
	Displays the search menu
	Displays your favorites menu
	Displays caller ID information
	Records live TV
	Reverses or fast forwards your program
	Scrolls through available TV inputs
	Stops your program
	Pauses your program
	Plays your program
	Reverses 7 seconds at a time or fast forwards 30 seconds
	Not currently available
	Displays recorded programs and schedules
	Increases or decreases TV volume
	Displays the interactive guide
	Changes channels or scrolls through menus
	Turns all sounds on or off
	Displays the last 5 channels you viewed